

1

How to properly assemble the AC1755DW.



2

Locate the **long tab** on the waist pad and the **sewn loop** on the desired side of the holster.



3

Insert and pull the long tab through the sewn loop. Make sure the velcro belt loop is facing out from the holster.



4

Be sure to pull the tab completely through!



5

Secure the hook and loop (velcro) on the tab and flap.



6



Fully assembled and ready to use.